




Three Square Market 3329 Casey St.  
River Falls, WI 54022 715.386.2233

# GONDOLA FIXTURE



- A - Deck
- B - FRONT TOE
- C - BACK TOE
- D - LEFT TOE
- E - SLEEPER
- F - RIGHT TOE
- G - BACK 1
- H - BACK 2
- I - BACK 3
- J - BACK 4



- \* Edge Banded
- A (Deck) Bottom Holes



Three Square Market 3329 Casey St.  
River Falls, WI 54022 715.386.2233

# GONDOLA FIXTURE

1. Lay out all fixture pieces onto a **COMPLETELY FLAT** surface. **\*Doing this on an uneven surface may produce breaks in the melamine.** Pound in all clips using the mallet and clip holder provided. **\*Hold the clip holder straight up and down.** Make sure all clips are open.
2. Lay A (Deck) on the floor, the bottom with five holes (**•see image on other side**) facing up.
3. Insert D (Left Toe) into A (Deck). Clips should be facing the right side of the fixture. Close the connected clips.
4. Insert E (Sleeper) and F (Right Toe) into A (Deck). Clips should be facing the left side of the fixture. Close the connected clips.
5. Insert B (Front Toe) and C (Back Toe) into D (Left Toe), E (Sleeper), and F (Right Toe). Clips should be facing the inside of the fixture. Close the connected clips.
6. Double check that ALL bottom clips are closed. Apply feet to the fixture. Flip the fixture over.
7. Insert G (Back 1) into A (Deck). Clips should be facing the back of the fixture. Leave the clips open, for now.
8. Insert H (Back 2) into A (Deck) and G (Back 1). Clips should be facing the right side of the fixture. Leave the clips open, for now.
9. Insert I (Back 3) into A (Deck) and H (Back 2). Clips should be facing the front of the fixture. Leave the clips open, for now.
10. Insert J (Back 4) into A (Deck) and I (Back 3). Clips should be facing the left side of the fixture.
11. Working in one direction around the fixture, line up all holes. **\*The rubber mallet is helpful for this.** Close all clips.
12. Double check that ALL clips are closed.
13. Set and screw the slatwalls into place, lining screws into slat grooves. **\*We recommend using 1" sheetrock screws.**
14. Insert all plastic slatwall inserts. **\*The lip of the insert should face the top of the fixture (see image on other side).**
15. Enjoy

**SEE THE ASSEMBLY VIDEOS  
ON 32FIXTURES.COM!**

**32FIXTURES.COM**